








Risco Wisdom

Resetting Mains Fault LED (and other indicated faults)

- Press:  Key
- Press Scroll Key  *To: View*
- Press:  Key
- Press Scroll Key:  *To: Faults*
- Press:  Key *Override Faults—Yes?*
- Press:  Key *To: Yes*
- Press:  Key